



KITS FOR : MixRite 2504 PO4 - Dosing rate 0.4-4%

Last update:
04/12/2007

	No.	PART	Cat/No.
<p>The diagram shows an exploded view of the dosing pump assembly. Key components include the motor (2), suction tube (7), suction piston (8), and various seals and O-rings. Sub-assemblies are highlighted with red boxes and labeled A through G:</p> <ul style="list-style-type: none">A: SEAL KIT (parts 41, 42, 48)B: SUCTION PISTON KIT (parts 8, 16)C: SUCTION TUBE KIT (parts 7, 55)D: CHECK VALVE KIT (parts 17, 19, 20, 21, 30, 48)E: MECHANISM SPRING KIT (parts 27, 29)F: SUCTION CYLINDER KIT O RING 2-021 PO (parts 46, 47, 49)G: U LATCH KIT (parts 16, 17)	A	SEAL KIT	3600000031
	B	SUCTION PISTON KIT	3600000050
	C	SUCTION TUBE KIT	3600000021
	D	CHECK VALVE KIT	3600000023
	E	MECHANISM SPRING KIT	3600000001
	F	SUCTION CYLINDER KIT O RING 2-021 PO	3600000003
	G	U LATCH KIT	36030167916